

# Overlay Instructions

THE APPLICATION OF VINYL DECALS REQUIRES A DEGREE OF DEXTERITY AND CONCENTRATION. IF YOU FEEL THAT YOU CANNOT APPLY THE DECAL YOURSELF, ANY AUTO DETAILER, WINDOW TINT, OR BODY SHOP CAN APPLY IT FOR YOU. WE CANNOT BE RESPONSIBLE FOR REPLACING DECALS THAT HAVE BEEN DAMAGED DURING APPLICATION.

Apply Decal at room temperature ( 55 to 75 degrees); avoid direct sunlight. Cold weather is not recommended because the adhesive doesn't stick in cold temperatures.

Step one: Thoroughly clean your factory emblem with windex and rubbing alcohol, removing all dirt and grime. Wipe dry and remove all dust/lint.

Step two: Lightly spray your emblem with Original Windex, prior to application. **Leave wet!**

Step three: Peel the underside-backing off the overlay, carefully! Do not touch the sticky adhesive side. Hold the decal by the non-sticky side only; careful not to let the decal fold upon itself or fall.

You may need to apply more windex at this point.

Step four: **Apply decal** to emblem and slide it into position. The windex should allow for the decal to slide right where you want it.

Step five: With a clean soft cloth or just your soft fingertips, (don't use a credit card or anything scratchy) start from the top center and rub down & outward to the edges, to remove the windex and any trapped air from beneath the overlay. Air bubbles will come out as you smooth the air from beneath. If small air bubbles remain, they should come out over time with sunlight.

You may want to apply WARM air (not hot!) from a hairdryer to help the moisture dry. Once the windex is dried from beneath the overlay it will stick completely and last for years.

*Do not wash your vehicle for a few days to assure the adhesives set completely.*

*Thank you for choosing PatriotDecals.com!!*

*Enjoy your new overlay!*