

SUPERDUTY INLAYS

THE APPLICATION OF VINYL DECALS REQUIRES A DEGREE OF DEXTERITY AND CONCENTRATION. IF YOU FEEL THAT YOU CANNOT APPLY THE DECAL YOURSELF, ANY AUTO DETAILER, WINDOW TINT, OR BODY SHOP CAN APPLY IT FOR YOU. WE CANNOT BE RESPONSIBLE FOR REPLACING DECALS THAT HAVE BEEN DAMAGED DURING APPLICATION.

Apply Decals at room temperature (55 to 75 degrees); avoid direct sunlight. Cold weather is not recommended because the adhesive doesn't stick in cold temperatures.

Inlays come with a clear application tape, so you can easily see where you want to place the letters. Use this tape to stick the decals in place; do not touch the underside of the actual decal. Once in place, press firmly and smooth out any trapped air. Then you can remove the clear tape from the top. Remember, patience is the key when installing decals.

If any air bubbles appear after installation, do not worry, they will come out on their own in a few days with sunlight.

Thank you! We hope you enjoy your custom inlays!!

-PatriotDecals.com